

# **Installation instructions**

PC-DMIS Q-DAS Converter

Version: 5.2020.137



# **Table of Contents**

Installation instructions PC-DMIS – Q-DAS Converter	
Required access rights	
PC-DMIS Q-DAS Converter	
Registry:	
File system:	
PC-DMIS:	
Registry:	
File system:	



### Installation instructions PC-DMIS – Q-DAS Converter

Dear customer.

you have ordered the PC-DMIS Q-DAS Converter software at Hexagon or you want to perform a test installation.

The software may only be installed on a **64-bit computer** with **Windows 7 or higher**.

The software is available for download at the following URL:

https://downloads.ms.hexagonmi.com/PC-DMIS\_Solution\_Modules/PC-DMIS-Q-DAS\_Converter/Version 5

Please perform the following steps to download the software on your PC-DMIS computer:

- 1. Check the PC-DMIS version currently being used.
- 2. Start the download via left click on the file.
- 3. Unpack the zip archive on the PC-DMIS computer.
- 4. Start the file "PCDQDAS\_Setup.exe" with administrator rights to install the software. Then follow the instructions in the set-up procedure.
- 5. After successful installation start PC-DMIS with administrator rights and open any measuring routine you like.
- 6. Start the Q-DAS Converter once with administrator rights via the related Windows start group.
- 7. You can then use the software with user rights. Both PC-DMIS and the Q-DAS Converter must be started with identical permissions.



## Required access rights

PC-DMIS and the PC-DMIS Q-DAS Converter requires full access to the areas described below in the file system and registry:

#### **PC-DMIS Q-DAS Converter**

#### **Registry:**

- "HKEY\_CLASSES\_ROOT\PCDLRN.Application\" and all subkeys
- "HKEY\_CURRENT\_USER\Software\VB and VBA Program Settings\" and all subkeys

#### File system:

- Installation directory and subfolder
- User-defined folders in which measuring routines are stored and executed
- "C:\ProgramData\PCDMIS\_Ergebnis\_Konverter\" and subfolder
- Folders defined in PC-DMIS Q-DAS Converter under "Preferences" and "Setup"

#### PC-DMIS:

#### **Registry:**

- "HKEY CLASSES ROOT\PCDLRN.Application" and all subkeys
- "HKEY\_CURRENT\_USER\Software\Hexagon\PC-DMIS" and all subkeys Optional:
- "HKEY\_LOCAL\_MACHINE\SOFTWARE\Wow6432Node\Hexagon\PC-DMIS" and all subkeys
- "HKEY\_USERS\.DEFAULT\Software\Hexagon\PC-DMIS" and all subkeys

#### File system:

- "C:\ProgramData\Hexagon\PC-DMIS" and subfolder
- "C:\Users\Public\Documents\Hexagon\PC-DMIS" and subfolder
- User-defined folders, in which measuring routines, probes, subroutines etc. are stored



# Compatibility of PC-DMIS with PC-DMIS Q-DAS Converter

The version number of the Q-DAS Converter informs about the compatibility to PC-DMIS:

- **X**. YYYY.y**ZZ**:
  - X, Z: Version number of PC-DMIS Q-DAS Converter
  - Y: Version number PC-DMIS
  - y: Release of PC DMIS
- **5.**2019.1**31**:

version number of PC-DMIS - Q-DAS Converter: 5.31 version number of PC-DMIS: 2019 R1

➤ This version is compatible with PC-DMIS 2019 R1 and higher.

Should you have any technical questions please contact your local PC-DMIS Hotline.